

LAPTOP & TABLET CHARGING TROLLEYS USER MANUAL



SPECIFICATION

Laptop & Tablet Charging Trolleys provide a secure way to store and charge devices while allowing for easy movement between rooms. They are equipped with high-quality braked castors for smooth mobility. This product is CE tested and complies with EU safety standards.

Laptop & Tablet Storage Trolley

Code	Description	Size H.W.D. mm
L7M121066X2	16 compartments, 2 doors	1200.1040.660

Narrow Aisle Laptop & Tablet Storage Trolleys

Code	Description	Size H.W.D. mm
L7M12526782	8 compartments, 2 doors	1200.525.670
L7M125212X4	16 compartments, 4 doors	1200.525.1220



TEL:
01384 899800

WEBSITE:
www.qmp.uk.com

EMAIL:
sales@qmp.uk.com

LAPTOP & TABLET CHARGING TROLLEYS USER MANUAL



LOCKER CONSTRUCTION

- Grade CR4 0.7mm mild steel, pop riveted carcass construction.
- Delivered assembled.
- Pre-drilled carcass for nesting lockers together.
- Each compartment is equipped with a 3-pin plug socket to permit charging using each laptop's own mains lead.
- Perforation holes down the left side of the carcass for ventilation whilst the laptop or tablet is on charge.
- Fitted with standard mastered cam locks with 2,000 differs.
- Reaction to Fire Classification EN13501-1.
- The door is attached by pop rivets to the right hand side of the carcass with two butt hinges and fitted with 10-disc key operated cam lock, supplied with 2 keys.

PAINT FINISH

- Three stage pre-treatment and phosphate coating.
- Carcass and doors are finished in a high-quality epoxy polyester full-gloss powder coating, oven-cured at 180°C, and incorporating a Germ Guard anti-bacterial additive for enhanced hygiene protection.
- Carcass powder coated with RAL 7035 Light Grey. Doors are powder-coated in the colour range below.

Door Colour Options	RAL
Light Grey	7035
Dark Grey	7024
Red	3003
Green	6024
Light Blue	5012
Dark Blue	5017
Yellow	1018



LAPTOP & TABLET CHARGING TROLLEYS USER MANUAL



SETTING UP

- Ensure the sockets inside the units are switched off.
- Connect each laptop to its assigned charging unit and plug the 3-pin plug into the sockets inside each compartment. (Do not switch on)
- Ensuring the switch is in the off position, plug the supply lead into the socket on the side of the unit (fig 1), Secondly plug into the main power supply, and switch on the main power (fig 2)
- Switch on the switch on the side of the unit (fig 1). Proceed to switch on the sockets inside the compartment one at a time, the indicator on the laptop will illuminate. NB. switch on only those in use.

FIG 1



FIG 2



FAULT FINDING

- Ensure the charging module is plugged into the laptop.
- Check that all the plugs are correctly fitted and all the switches are on.
- Check the fuse or RCD in the supply board has not blown or tripped. Reset and try again. If the board continues to trip consult an electrician.
- Check the fuse in the three-pin plug (13amp) - replace if blown.
- Check the 10amp fuse in the holder next to the switch on the unit (Fig 3), there is a spare fuse in the holder Fig 4). If the unit continues to blow fuses, consult your supplier. It is important that this fuse is a slow blow or anti-surge fuse marked with a 'T'.

FIG 3




FIG 4



LAPTOP & TABLET CHARGING TROLLEYS USER MANUAL



REPLACEMENT SWITCH INSTRUCTIONS

1. Unplug unit from mains supply.



2. Carefully prise switch from carcass, and disconnect wires.



3. Fit new switch reconnecting push on connectors.



4. Refit switch into carcass.

LAPTOP & TABLET CHARGING TROLLEYS USER MANUAL



OPERATING CONDITIONS & INSTALLATION

- Indoor use only — do not install in external or damp/condensing environments.
- Position on a stable, level surface, away from vibration, moving equipment or impacts.
- Do not block vents — leave space around the locker for airflow, wiring and servicing.
- Avoid heat sources such as radiators, direct sunlight or other warm equipment.
- Keep away from corrosive or wet areas (e.g., chemicals, salt spray, cleaning wash-down, open water).
- Use a suitable earthed mains supply; RCD protection is recommended following a risk assessment.
- Use only approved charging cables and devices from reputable manufacturers.
- Do not use damaged cables or devices — check for fraying, cracks, swelling or loose pins before use.
- Do not overload the sockets — only connect tablets/laptops/phones intended for charging.
- Ensure doors can open fully and that compartments are easily accessible to users.
- Do not block fire routes or ventilation grills when locating the unit.
- Inspect and maintain periodically; only competent personnel should carry out electrical or mechanical work.

CLEANING & MAINTENANCE

- Empty all compartments and remove devices before cleaning.
- Dust all surfaces (including vents/holes) using a soft, dry cloth — avoid abrasive materials.
- Wipe down inside and out with warm soapy water or a mild foaming cleaner; then disinfect surfaces including door locks and handles.
- Avoid using cleaners containing strong solvents (e.g., acetone, methylene-chloride, strong acids) that can damage powder-coat finish.
- Leave locker completely dry before returning devices and plugging in for use.
- Periodically inspect hinges, locks, and electrical sockets: oil hinges lightly with a light machine oil (e.g., 3-in-1) and replace any damaged or faulty components.
- Conduct a maintenance check at least annually (or more frequently in heavy-use environments): verify ventilation is unobstructed, ensure no corrosion or damage to steelwork, check socket wiring and RCD protection remain correctly functioning.

LAPTOP & TABLET CHARGING TROLLEYS USER MANUAL



LABEL ALLOCATION

ZLOCLABEL015

Voltage	230V AC
Frequency	50Hz
Phases	1
Max Power Rating	2300W
Fuse Rating	10 Amp

ZLOCLABEL003



Quality Metal Products LTD,
Timmis Road, Lye, Stourbridge DY9 7BQ.
www.qmp.uk.com

APPLIANCE CHARGING LOCKER

Model Number:

Serial Number:


Date:

ZLOCLABEL014



ZLOCLABEL016





Tested By:

Next Test due:



SCAN FOR USER MANUAL

ELECTRICAL COMPONENT SPECIFICATION

Description	Standard/Tests
Cabinet power supply lead (1.5mm minimum)	BS6500-BS6500 200
Power supply lead to be fitted with a 13A ceramic fuse to specification	BS1363/A- BS13635:2008
Mains power lead cabinet connection female socket. 13A rated	EN60320
Cabinet identification label	BS7671:2018+A2:2022 (717.514)
Earth connection warning notices are to be permanently fixed in accordance with specification	BS7671: 2018+A2:2022 - (514.13.1 i & ii)
Cabinet incoming switched, fused connector, ceramic fuse 5 x 20mm rating 9A - Statement of conformity & certification as issued by the manufacturer	

LAPTOP & TABLET CHARGING TROLLEYS USER MANUAL



EU DECLARATION OF CONFORMITY

In accordance with European Parliament and Council Decision No 768/2008/EC Annex III. **Declaration is issued under the sole responsibility of the manufacturer.**

The object of the declaration described above is in conformity with the relevant EU harmonisation legislation:

2014/35/EU	Low Voltage Directive
2014/30/EU	Electromagnetic Compatibility (EMC)
2011/65/EU	Restriction on the use of certain hazardous substances (RoHS)

References to the relevant harmonised standards used or referenced to the other technical specifications in relation to which conformity is declared:

<u>Reference & Date</u>	<u>Title</u>	<u>Edition</u>
EN60335-1	Household and similar electrical appliances. Safety - General requirements	2012/A15:2021
EN61000-6-1	Electromagnetic compatibility (EMC) - Part 6-1: Generic standards - Immunity for residential, commercial and light-industrial environments.	2007
EN 61000-6-3	Electromagnetic compatibility (EMC) - Part 6-3: Generic standards - Emission standard for residential, commercial and light-industrial environments.	2007/ A1:2011/ AC:2012
EN IEC 63000	Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances.	2018

LAPTOP & TABLET CHARGING TROLLEYS USER MANUAL



TROUBLE SHOOTING & GENERAL CHECKS

- **Verify mains power** - Ensure the locker is plugged in and the circuit breaker or fuse feeding it is not tripped or blown.
- **No power detected** - Confirm the wall socket is live by testing with another device. If the socket works, inspect the plug, power cable and any fitted RCD for visible damage. Do not continue using the locker if you find a fault – contact a qualified electrician.
- **Check plug specification** - QMP laptop charging trolleys are supplied with an RCD plug. Confirm the plug type is correct for your installation.
- **Inspect ventilation** - Ensure the surrounding area has adequate ambient ventilation to prevent overheating.
- **Inspect cables** - Look for loose, bent or damaged connectors. Faulty cables or ports can prevent charging or pose a safety risk. Replace any damaged parts immediately.
- **Check device (laptop/tablet) condition** - A non-charging device may be due to the device's own battery or charger fault rather than the locker. Test the device outside the locker to verify.
- **Inspect internal sockets** - Confirm the individual mains in each compartment are firmly in place and free from discolouration, arcing or melting. Stop using the compartment if any damage is found.
- **Lock and access checks** - Ensure compartments are properly closed/latched; an open door or poor lock operation might affect safety features or prevent charging from starting.

REPLACEMENT LOCKS & SPARE KEYS

- Replacement locks are available from: **QMP Ltd**, Timmis Road, Lye, Stourbridge, West Midlands, DY9 7BQ.
Tel: 44 (0) 1384 899800. **Website:** www.qmp.uk.com. **Email:** sales@qmp.uk.com
- Spare or replacement keys for the lockers are available from: **Fast Key Services Ltd**, Pilot Close, 3 Fulmar Way, Wickford, Essex, SS11 8YW.
Tel: 01268 562592. **Website:** www.fastkeys.co.uk. **Email:** sales@fastkeys.co.uk